Jaguar Numeric Pager

User Manual

We thank you for making the ultimate choice to purchase the Jaguar pager. Your new jaguar pager will help you keep in touch while on the move, be it business related or leisure. The Jaguar pager is designed with ease of operation in mind and it aims to provide you with many years of reliable service. This user manual explains how the various features operate and provide important instructions to help the user get familiarized with the operation of this unit.

Contents

1. Pager Standard Features 5
2. Buttons 6
3. Definition of Types of Icons 7
4. Inserting/Replacing Battery 8
5. Selection of Alert Mode 9
6. Overview of Other Built-In Functions 11
7. Selecting Beep/Chirp/Melody Alert 12
8. Key Tone/On Off 13
9. Erase All 14
10. Setting the Time and Date 15
11. Setting the Alarm 16
12. Setting Auto On/Off 18
13. Turning On/Off the pager 20
14. Receiving and Reading Messages 21
15. Reading Stored & Locking Messages 23
16. Locking and Unlocking Messages 26
17. Deleting Messages 29

Page 5

1. Pager Standard Features

The jaguar provides the following features as standard:

- 1 line display (1 line x 12 digit)
- Total memory capacity: 400 digits (20 digit x 20 messages)
- Locks up to 20 messages
- 3 standard alert modes: sound, vibrate and silent
- 4 beep, 1 chirp and 5 melody alerts
- Key tone on/off
- Real time clock (12 hours) with calendar date display

- Alarm clock
- Delete individual message or erase all
- Service area indication
- Automatic power on/off
- Low battery indication
- Back lighting
- Reminder alert

Page 6

2. Buttons

(image)

Select Button: Turn the back light on and enter into the function change mode.

Read Button: Read message and set the pager function mode.

Page 7

3. Definition and Types of LCD Icons

(image)

(image) Sound

(image) Vibration

(image) Melody

(image) Auto On/Off

(image) Alarm

(image) Message Lock

(image) Message Full

(image) Low Battery

(image) Duplicate Message

(image) Receivable Area

(image) Message Extension

Page 8

4. Inserting/Replacing Battery

1. Slide the battery locking switch to the unlock position.
2. Slide the battery cover and separate it from the pager.
3. Insert the battery, paying attention to the battery polarity marked in the battery compartment.
4. Slide the battery cover back on the pager and slide the battery locking switch to the locked position.

(image)

Page 9

5. Selection of Alert Mode

Sound Mode, Vibration Mode, Silent Mode

You can change the alert mode in a serial order of Sound Mode, Vibration Mode and Silent Mode. After inserting battery, the initial alert mode is Sound Mode.

(image)

Sound Mode

If you want to change Sound Mode to Vibration Mode, press the SELECT button twice, then “VIBRATE ?” will appear.

(image)

Page 10

If you press the SELECT button once more, the pager will return to the standby mode displaying the current time and the vibration icon will appear indicating the change was made.

(image)

Vibration Mode

As this, you can also change Vibration Mode to Silent Mode or Silent Mode to Alert Tone Mode in the same manner.

(image)

Silent Mode

Page 11

6. Overview of Other Built-In Functions

The jaguar has 7 menu functions. These are “SET MELODY”, “KEY TONE ON/OFF”, “ERASE ALL”, “SET TIME”, “SET ALARM”, “SET AUTO ON/OFF” and “POWER OFF.”

Be pressing the SELECT button twice and the READ button once you’ll enter into the menu functions.

Page 12

7. Selecting Beep/Chirp/Melody Alert

Press the SELECT button twice and the READ button once to the “SET MELodY ?” mode.

You can choose any one of the desired beep tones, chirps or melodies.

Press the SELECT button again and the current tone will sound and its corresponding number will appear as displayed blow.

(image) (image)

If you press the SELECT button once more, the next alert tone number is displayed and the corresponding alert tone will sound. Press SELECT button to select the desired alert. pager returns to standby after that.

Page 13

8. Key Tone On/Off

Press the SELECT button twice and the READ button twice, “KEY TonE ?” menu will appear.

(image)

If you press the SELECT button, the current setting will be displayed and blinking.

(image)

To change “ON/OFF” setting, press the READ button and the setting will be toggled between “On” and “Off”.

After selecting “On” or “Off”, press the SELECT button to return to the standby mode.

Page 14

8. Erase All

If you want to erase all stored unlocked messages, press the SELECT button twice and the READ button three times to the “ERASE ALL” mode. Press the SELECT button once and “dELETEd” is displayed and all stored messages except locked messages are erased.

(image) (image)

Page 15

10. Setting the Time and Date

Press the SELECT button twice and the READ button four times, “SET TIME ?” menu will appear.

(image)

Press the SELECT button and the month number will be blinking; press the READ button to the desired month and then press the SELECT button.

(image)

After that the day number will be blinking and you can set the desired day. Repeat the procedure for hour, minute and AM/PM selections.

Page 16

11. Setting the Alarm

Press the SELECT button twice and the READ button five times, “SET ALARM ?” menu will appear.

Press the SELECT button and “ALARM oFF” will be displayed.

(image) (image)

This can be toggled between “ON” and “OFF” by pressing the READ button.

(image)

Page 17

If you want to use the ALARM function, select “ALARM ON” and press the SELECT button, and you can set the desired ALARM time by the procedure in “SETTING TIME”.

(image)

If you press the SELECT button in the state of displaying “ALARM oFF”, pager will return to the standby mode.

Page 18

12. Setting Auto On/Off

Press the SELECT button twice and the READ button six times, “SET Auto ?” menu will appear.

(image)

Press the SELECT button, “Auto oFF” will be displayed.

(image) (image)

Page 19

If you want to use the AUTO ON/OFF function, select “Auto on” by pressing the READ button; press the SELECT button and you can set the desired AUTO ON/OFF time by the procedure in “SETTING TIME”.

(image) (image)

If you press the function button in the state of displaying “Auto oFF”, the pager will return to the standby mode.

Page 20

13. Turning On/Off the pager

Press the SELECT button twice and the READ button seven times, the “PoWER oFF” menu will appear.

(image)

Press the SELECT button again and the pager will be off.

(image)

If you want to turn on your pager that is off, press the READ button for one second; two short beeps will emit and the pager will enter into the standby mode.

Page 21

14. Receiving and Reading Messages

When a message is received by your pager, the alert will last for 8 seconds and the received message is displayed, for example, as below:

(image)

If you press the SELECT button or the READ button the alert stops. If the message is exactly the same as one in memory, the duplication icon will appear.

(image)

Page 22

In the standby mode if there are unread message the LCD is displayed as below, instead of displaying the current time.

(image)

The number between the brackets is the number of unread messages.

Page 23

15. Reading Stored & Locked Messages

Press the READ button, the message is displayed on the LCD as below. Messages are from the most recent to the oldest messages in memory.

(image)

If the stored message is more than 12 characters long, the message extension icon will appear.

(image)

Page 24

If you press the READ button again, the rest of the message will be displayed.

(image)

If you press the READ button after reading the message, the following information will be displayed:

(image)

01]: Storage number

31: Day message received

12:50P: Time message received

Press the READ button and the next message will be displayed.

P age 25

You can read the locked message after you read all the stored messages. In case of locked message, the locked icon will appear and there is no information of the message.

(image)

If the current message is the last one, the pager returns to the standby mode.

If there are no stored messages, “No CALL” will be displayed.

(image)

Page 26

16. Locking and Unlocking Messages

To lock a stored message, press the READ button to the message you want locked, press the SELECT button once in the state of reading a message and the pager will ask you whether you want to lock the message or not.

(image)

If you press the READ button, the message is locked and “LocKEd” is displayed.

(image)

Page 27

If the message is exactly the same as one already locked, “duPLICATE” will be displayed.

(image)

If the locked message is full (20 messages), “MSG FuLL” will be displayed.

(image)

Note: The pager will lock 20 messages and still receive an additional 20 messages.

Page 28

To unlock a locked message, press the buttons in the same order as one in the above locking process, “UnLocK ?” will be displayed. If you press the READ button, the message is unlocked and “UnLocKEd” is displayed. If you press the SELECT button, not the read button, the message is displayed again.

(image) (image)

Page 29

17. Deleting Message

To delete a message selectively, press the function button twice in the state of displaying the message you want to delete, and “dELETE ?” will appear.

(image)

At this time if you want to delete the message, press the read button and the message is deleted, and “dELETEd” is displayed. If you press the function button, the message is displayed again.

(image)

Page 30

Battery Information

The pager is designed to operate with a “AAA” size alkaline battery.

Note: Do not use carbon zinc battery.

Caution: Ensure battery polarity is correct before installing battery.

Page 32

This device complies with part 15 of FCC Rules. Operation is subject to the condition that device does not cause harmful interference.

Caution: Any change or modifications in constructions of this device which are not expressly approved by the party responsible for compliance could voice the user’s authority to operate the equipment.